

GoMoorhead Internet Setup Instructions

What equipment do I need?

Laptop – There are four ways to connect a laptop to GoMoorhead-MSUM:

- 1) Most laptops purchased within one year come with an **internal wireless card**, if you have one this should be all that you need! (Mobile use)
- 2) If you do not have one, you should purchase a **PCMCIA wireless adapter** that is 802.11g capable. (Mobile use)
- 3) You can rent either the **GoMoorhead bridge** (stationary use) or the **GoMoorhead PCMCIA card** (mobile use)
- 4) Purchase a **USB wireless adapter** that is 802.11g capable (stationary use)

Desktop – There are three ways to connect a desktop computer:

- 1) Purchase a **USB wireless adapter** that is 802.11g capable
- 2) Purchase a **PCI wireless adapter** that is 802.11g capable
- 3) Rent the **GoMoorhead bridge** and connect it to your computers Ethernet port(network card)

How do I install my equipment?

- If you are using the **GoMoorhead bridge** all you will need to do is plug it into your computers Ethernet (network) port, it is pre programmed to work with GoMoorhead-MSUM!
- If you have a wireless card (**USB, PCMCIA, PCI**) you will need to install the drivers that came with the card – Please follow the manufacturers directions exactly to do this!
- If you have an **internal wireless card** on your laptop it should already be installed when you purchased it!

How do I make my equipment work with GoMoorhead-MSUM?

- Once your equipment is installed you will need to set the network name (SSID) to **GoMoorhead-MSUM** **Note:** If you type in the SSID it must be **EXACTLY** as shown and it is **Case sensitive**
- Depending on your wireless card manufacturer and computer operating system the process for connecting to a wireless card will vary. This is a general description for doing this with WindowsXP:
 - Click **Start > Run... >** type in **control** and press **Ok** - you are now in the **control panel**. From here you will need to click on **switch to classic view** in the upper left corner of the window > then double click on **network connections**.
 - There should be an icon that in the network connections window labeled **Wireless network connection**, Right click this icon and select **Find a wireless network**, now you will see either a list of nearby wireless networks, click on **GoMoorhead-MSUM** and then click connect in the bottom right corner, you may be prompted that the network is not secured, click **connect** anyways and you should be ready to surf the web!
- **Note: Do not try and connect to GoMoorhead; that network requires a username and password.** If you are being directed to a GoMoorhead login screen, you need to try and re-connect to **GoMoorhead-MSUM** and possibly **remove the GoMoorhead profile** from your computer. – **See back page for directions for doing this.**
- If you do not see a list of wireless networks, and instead you see an error message similar to “windows cannot control your wireless adapter”, then you will need to refer to your wireless card manufacturer’s instructions for connecting to a wireless network.

NOTICE: There will be NO COPYRIGHT INFIRNGEMENT allowed on the GoMoorhead – MSUM network. We will not make exceptions to this policy.

Still having Trouble?? Check the back page for advanced problem solutions